



Remark:

- <01>.Fasten rebar by steel wire & put H beam on top of it , ensure its levelling by level gauge.
- <02>.Cast H beam into concrete base , careful not to shift it during liquid concrete pouring.
- <03>.Foundation H beam specs:200X200.
- <04>.Mixing ratio of concrete : cement/sand/gravel/ :1: 2: 3.